

## Instructions for SKATER Control Software Update

for use with SKATER Turntable

### IMPORTANT NOTE

The SKATER Control units (SCU) that shall be used with the SKATER Turntable must have the software update skater-smp 1.1.10.s19 installed to work smoothly.

SKATER Control units purchased after July 2008 are already prepared to work perfectly with the SKATER Turntable, also indicated by a sticker on the back of the SCU.

SKATER Control units purchase before July 2008 and without a sticker indicating the update may need an software update. For the software update of the SKATER Control update cable (#20173) is necessary as well as the appropriate software. The update cable can be purchased from P+S Technik. Please download the update instructions and the appropriate software from our website using the link

[http://www.pstechnik.de/en/download\\_control.php](http://www.pstechnik.de/en/download_control.php)

Please read these instructions first and follow the steps carefully.

1.) To accomplish the software update, make sure you have the following items at hand:

- SKATER Control (#23786)
- Power supply and cable for SKATER Control
- SKATER Control update cable, Fischer 7-pin to serial (RS232) (#20173)
- Computer or Laptop with serial or USB connection
- USB to serial (RS232) adapter and appropriate driver (if you use the USB connection), available from computer store
- SKATER Control Software Update Package, available from our website using the link [http://www.pstechnik.de/en/download\\_control.php](http://www.pstechnik.de/en/download_control.php)

2.) Connect the SKATER Control unit to the computer using the update cable (#20173) and the serial to USB adapter, if applicable. Connect the SKATER Control to an appropriate power supply and turn on.

3.) Extract the file SCupdate\_XXXXXX.zip into on directory on the computer you are using for the update process. Read the User Guide Cupdate.pdf to get familiar with the Cupdate software

4.) Start the Cupdate software by double-clicking the file "CUpdate-3.x.xx.exe". Choose appropriate COM port.

5.) Select "SKATER – Skater Main Print (SMP)" in the Select module to update-drop down menu.

6.) Select "skater-smp 1.1.10.s19" in the Select file to update box. Compare version number.

7.) The update button shall now be active. Press update and follow the instructions on the screen.